## H701B-456

## Straight Pulling Head for CHERRYMAX® fasteners

**INSTRUCTION SHEET, Page 1 of 2** 

### DIMENSIONAL DATA (see Fig. 1)

Weight: 0.15 Lbs.




Fig. 1. Dimensional Data

#### **CHOICE OF RIVETERS**

- G746A (1850 Lbs @ 90 PSI, 7/8" stroke)
- G747 (2100 Lbs @ 90 PSI, 7/16 stroke)
- G704B (3100 Lbs @ 90 PSI, ½" stroke)
- G800 (4200 Lbs, 3/4" stroke, hand powered)

#### MOUNTING INSTRUCTIONS

- Attach Riveter to air source; place the spring into the riveter piston
- Carefully thread in and tighten the collet assembly onto the riveter piston
- . Thread in the sleeve assy and lock it in by tightening the Jam Nut.

#### JAW ADJUSTMENT

The jaws can be adjusted to hold onto the stem in position at all times or to fully release it before and after fastener installation

- Push the fastener all the way through the nosepiece.
- To grab onto the stem: Unthread the sleeve while moving the fastener in and out until you feel the desired jaw hold.
- To release the stem: Thread the sleeve in until the stem is released
- After adjustment, lock in position by tightening the Jam Nut.

#### **OPERATING INSTRUCTIONS**

#### Before operating the tool, make sure that:

- Pulling Head is correctly mounted on the proper riveter
- Proper Air source is connected (see Riveter manual for air pressure).

#### **During Operation:**

- Inspect the active area of the nosepiece regularly.
- Keep the tool clean, especially the nosepiece and jaws; pay special attention when sealants and adhesives are used.
- If stem slippage occurs, clean or replace the jaws.
- When installing -4 diameter Cherrymax and jamming occurs, the Jaw Follower (item 7a) may be replaced by the extended version (955-011). Please note that 955-011 must be purchased separately.




### H701B-456

# Straight Pulling Head for CHERRYMAX® fasteners

**INSTRUCTION SHEET, Page 2 of 2** 

#### PARTS LIST AS PURCHASED

ITEM	PART	DESCRIPTION	QTY.
No	NUMBER		
1	701B21	SLEEVE	1
2	701B25	RETAINING SPRING	1
3	701B24	STEM STOP (FINGER)	1
4	671A16	JAM NUT	1
5	701B29A	COLLET	1
6	701B18	JAW SET (2 PCS)	1
7	753A14A	JAW FOLLOWER (see operating instructions)	1
8	701A33	BUMPER	1
9	P-1155	COMPRESSION SPRING	1



#### PREVENTATIVE MAINTENANCE

- Clean and inspect the nosepiece, jaws, collet & spring every 1000 installations or whenever a failure occurs; replace spring and jaws if worn.
- Lubricate outside configuration of the jaws with Lubriplate® or similar light grease.
- Inspect regularly and keep active area clean and in good working condition.
- Replace worn or broken components.
- When re-assembling align the jaws with the jaw follower as shown in the exploded view (items 6 and 7a).

LOCTITE® is a registered trademark of Henkel Corporation. LUBRIPLATE® is a registered trademark of Fiske Brothers Refining Co.

#### WARRANTY

Seller warrants the goods conform to applicable specifications and drawings and will be manufactured and inspected according to generally accepted practices of companies manufacturing industrial or aerospace fasteners. In the event of any breach of the foregoing warranty, Buyer's sole remedy shall be to return defective goods (after receiving authorization from Seller) for replacement or refund of the purchase price, at the Seller's option. Seller agrees to any freight costs in connection with the return of any detective goods, but any costs relating to removal of the defective or nonconforming goods or installation of replacement goods shall be Buyer's responsibility. SELLER'S WARRANTY DOES NOT APPLY WHEN ANY PHYSICAL OR CHEMICAL CHANGE IN THE FORM OF THE PRODUCT IS MADE BY BUYER. THE FOREGOING EXPRESS WARRANTY AND REMEDIA ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES AND REMEDIAS; ANY IMPLIED WARRANTY AS TO QUALITY, FITNESS FOR PURPOSE, OR MERCHANTABILITY IS HEREBY SPECIFICALLY DISCLAIMED AND EXCLUDED BY SELLER. This warranty is void if seller is not notified in writing of any rejection of the goods within ninety (90) days after receipt

MERCHANTABILITY IS HEREBY SPECIFICALLY DISCLAIMED AND EXCLOSED BY SELECTION MAINTAIN, OF THE MERCHANTABILITY IS HEREBY SPECIFICALLY DISCLAIMED AND EXCLOSED BY SELECTION OF THE MERCHANTABILITY IS HEREBY SPECIFICALLY IN SECURITY IN THE MERCHANTABILITY IS HEREBY SPECIFICALLY OR CONSEQUENTIAL DAMAGES ARE HEREBY EXPRESSLY EXCLUDED.

Our policy is one of continuous development. Specifications shown in this document may be subject to changes introduced after publication.

NOTE: The properties, strength, dimensions, installed characteristics and all other information in these materials are for guidance only to aid in the correct selection of the products described herein and is not intended or implied as part of the above warranty. All applications should be evaluated for functional stability and available samples of the described parts can be requested for installed tests, suitability and evaluations.

